

Vista Quantum HDR: Firmware Upgrade Procedure Via USB2

There are different sets of files for the 8/16way DVD units, 4 way DVD units, and 4way non-DVD units, please ensure that you select the correct files for your unit..

Note: To complete the upgrade you will have to initialize the unit this will cause a loss of the units configuration, please make a note of any relevant setting. Then power down the unit then remove the power to the unit.

Procedure:

Un-zip the supplied .zip file to, the root directory of an empty USB2 memory drive, (do not un-zip the “.gz” file – this is a special zip file required for the upgrade).

Plug the USB2 drive into the front of the Quantum, wait a moment and ensure that the USB symbol appears on the monitor screen.

Press the “Menu” key and navigate to: System Set >Program Update.

If the software on the USB2 drive is newer than that on the Quantum you will see the “New Software Found” prompt.

Press the Select key and wait for the upgrade to finish.

Go to the following Menu and Initialize the unit, select Initialization and press select, this will reset all user setting to default including the IP address.

Menu: System Set > Basic > Initialization.

Remove the USB2 drive and re-cycle the power on the Quantum by pressing the ON/OFF button and entering the password (00000000 by default).
Remove power for about 10 seconds.

When the unit has powered down turn it back on and the new firmware will be loaded.

To check that the upgrade was successful check the dates on the supplied files with the data found in the Quantum menu.

Menu: System Set > Basic > Information.

(if the cu-boot file was supplied with this upgrade it will not be shown in this menu)

Now re-enter the units settings noted before the upgrade.

The upgrade, via a USB2 drive is now complete.