

Installation Note


4105-2 Memory Expansion module

IN053

Installing a 4105-2 Memory Expansion module in a 4101-2 Controller

The memory expansion module plugs into its own special connector in the 4101-2 Controller motherboard. The connector is labelled CONN12.

1. Disconnect the power to the Controller.
2. The position of CONN12 is shown in the diagram below.



3. The memory expansion module must be installed with the component side of the board facing the top of the controller motherboard as shown below.



4. Insert the connector on the memory expansion module into CONN12. Make sure that all the pins are engaged and that none are hanging over the side of CONN12.

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect equipment into an outlet on a circuit different from that to which the receiver is connected.